

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
07054	15514	S.S. TIMER SWITCH
P010086	15697	WATER FILTER ELEMENT
P010192	15682	MUFFLER - 3/8MPT INTAKE
P010196	15718	ASSY HEATLESS DRYER
P010444	15652	COMPRESSOR 3/4 HP - 220-1-50/60
P010485	15703	ADAPTER PLATE
P010491	15653	COMPRESSOR MAINTENANCE KIT
P010499	15649	HEATLESS DRYER MAINTENANCE KIT
P010589	15851	BOX LOUVER KIT
P01109	15002	PRESSURE SWITCH REPAIR KIT
P01238	15003	ECCENTRIC 4200
P01348	15201	HUMIDITY BOARD
P01500	15006	4-WAY SOLENOID VALVE
P01545	15007	PRESSURE REGULATOR REPLACEMENT
P01548	15008	PRESSURE REGULATOR
P01577	15540	ADAPTER 1/8" FPT X 1/8" MPT
P01603	15454	PIPE SHAPER
P01611	15009	BYPASS SOLENOID (P-0500D)
P01616	15370	REGULATOR
P01768	15861	NUT AND SLEEVE ASSY
P01775	15011	HOT GAS BYPASS VALVE
P02235	15014	AIR FILTER,P-3100/4200 STD, TI
P02236	15015	WIRE HARNESS,CABINET 4200
P02253	15016	CONTROL RELAY
P02281	15017	PRESSURE GAUGE 0-30PSI
P02282	15205	LOW PRESSURE ALARM SWITCH
P02293	15018	AIR COMPRESSOR, P-3100 3/4HP
P02358	15443	ELAPSED TIME METER
P02496	15366	FAN MOTOR 16000/24000
P02533	15327	HOUR METER
P02570	15418	AIR COMPRESSOR,P-16800
P02577	15019	HUMIDITY SHUT-OFF SOLENOID
P02581	15020	OUTLET BYPASS VALVE
P02619	15022	FILTER ASSEMBLY, AIR INTAKE
P02623	15023	POWER RELAY
P02626	15024	VIBRATION MOUNT
P02626S	15483	VIBRATION MOUNT
P02629	15345	ALARM INDICATOR
P02725	15026	CYCLE TIMER
P02869	15670	MANUAL 3100/4200TI
P02900	15027	DOOR SWITCH (FAN CONTROL)
P02964	15305	KIT FOR P-50001285
P03083	15029	REBUILD KIT, P-15-389
P03311	15587	DESICCANT DRYING CHAMBER
P03375	15618	PRESSURE SWITCH, 20PSI ON-40 OFF
P03519	15030	POWER CONTACTOR
P03659	15374	FUSE
P03664	15031	HEATER (MODEL 24000)
P03745	15032	FAN
P03817	15033	MAJOR REPAIR KIT,P-15-373/3271
P03837	15034	MUFFLER

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
P03965	15035	WIRE HARNESS (LG. BACK)
P05038	15625	MAINTENANCE KIT-P-05000
P05049	15331	CIRCUIT BREAKER, 8 AMP
P05099	15310	OUTLET PRESSURE REGULATOR
P05136	15036	MINOR REPAIR KIT, P-15-373/3721
P05137	15037	SEAL REPAIR KIT,P-15-373/3271
P05151	15300	CIRCUIT BREAKER, 15 AMP
P05216	15038	CIRCUIT BREAKER, 3 AMP
P05285	15563	FAN COOLING
P05443	15685	FLOW TRANSDUCER 0-95
P05451	15039	CENTRIFUGAL SWITCH, DORERR
P05452	15040	CENTRIFUGAL SWITCH,GE
P05466	15285	PRESSURE REGULATOR
P05504	15723	COMPRESSOR HEAD GASKET
P05574	15042	ROTATING MECHANISM, DOERR
P05723	15045	ROTATING MECHANISM (GE)
P05838	15330	HUMIDISTAT BOARD
P05847	15608	REPLACEMENT CONTROL BOARD KIT
P05860BA1	15749	BOTTLE NITROGEN REPLACEMENT UNIT
P05893	15564	FILTER AIR INTAKE
P05917	15047	COIL FOR 4-WAY VALVE
P05941F1	15617	TEE-MRUN 1/8 MPT 1/8 PRSLK SWVL
P05961	15595	MANUAL-INSTR,16/24KD
P05969	15048	ELBOW FITTING 45 DEGREES (16-24)
P05992	15317	SSR P-3100/4200DCO
P06131	15049	CABINET FILTER P-05000
P06136	15050	CIRCUIT BREAKER, 15 AMP
P06137	15051	CIRCUIT BREAKER, 20 AMP
P06138	15324	ON-OFF BREAKER SWITCH - 20000D
P06184	15052	CIRCUIT BREAKER, 30 AMP
P06290	15054	CAPILLARY TUBE, P-16000/24000D
P06337	15055	BATTERIES
P06346	15423	4-WAY SOLENOID VALVE 16/24D
P06348	15056	WATER FILTER ELEMENT,9 3/4" 16/24D
P06415	15057	FILTER FELT, P-5000-5-5 P06420 15058 FLOAT SWITCH,8/12/16/24D
P06423	15537	4-WAY VALVE
P06521F1	15208	SS TIMER,HEATLESS DRYER 120V
P06521F2	15209	SS TIMER,HEATLESS DRYER 240V
P06658	15059	CABINET FILTER P-8000/12000DCO
P06710G1	15433	KIT, SS TIMER 120V
P06710G2	15432	KIT, SS TIMER, 240V
P06738	15060	SOLENOID VALVE
P06739	15061	SOLENOID VALVE
P06775	15385	CYCLE TIMER BOARD 8000/12000DCO
P06788	15063	PRESSURE ALARM SWITCH
P06799	15341	4-WAY VALVE 8000,12000DCO
P06824	15064	WATER FILTER ELEMENT 4 1/2"
P06827	15272	WATER FILTER HOUSING
P06827G1	15216	WATER FILTER KIT, P-8000/12000DCO
P06827G2	15270	WATER FILTER KIT, P-10000/16000DCO
P06859	15065	SOLENOID VALVE
P06885	15066	MAINTENANCE KIT 8/12K, 10/15K

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
P06905	15306	TOWER OUTLET FILTER
P06916F1	15420	SHUTTLE VALVE
P06916F2	15411	SHUTTLE VALVE
P06916F3	15448	SHUTTLE VALVE
P06916F4	15449	SHUTTLE VALVE
P07011		MAINT KIT – G526
P07036	15326	HUMIDISTAT
P07054	15067	S.S.PRES. SWITCH,FRANKLIN
P07071	15455	BATTERY FOR ALTERNATOR
P07101	15068	SKINNER VALVE ASSY.
P07268	15667	SOLENOID VALVE 8/12K-DCO
P07353	15288	FILTER
P07390	15303	HUMIDITY BY-PASS VALVE
P07400	15410	VALVE BODY
P07420	15363	PURGE SOLENOID
P07511	15069	MAINTENANCE KIT,P-05000D,P-31/42DCO
P07584	15070	MAINTENANCE KIT W/ SENSOR P-31/42
P07586	15071	MAINTENANCE KIT W/SENSOR, P-8/12DCO
P07587	15072	MAINTENANCE KIT W/SENSOR P-16/24DCO
P07588	15073	MAINTENANCE KIT W/SENSOR P-16/24
P07589	15074	MAINT. KIT W/SENSOR 05000D
P07614	15445	REPAIR KIT, 4-WAY, CHATLOS
P07626	15550	AIR COMPRESSOR
P07677	15439	HIGH/LO PRESSURE ALARM
P07707	15271	BY-PASS RELIEF VALVE
P07856	15522	FILTER
P08118	15468	PRIMARY OPTICAL SENSOR
P08147	15289	HIGH PRESSURE REGULATOR
P08192	15590	AIR COMPRESSOR
P08217	15437	TEMPERATURE SENSOR
P08218	15464	AIR COMPRESSOR P06500D
P08222	15467	OPTICAL SENSOR
P08595	15436	FOUR-WAY VALVE
P08596	15466	4-WAY VALVE ASSY
P08625	15676	HOSE
P08626	15728	HOSE
P08649	15322	FLEX TUBE (19")
P08650	15323	FLEX TUBE (16.5")
P08651	15484	45 DEGREE ELBOW FLARE (20-30D)
P08654	15688	FLOW TUBE ASSEMBLY
P08656	15295	MAINT. KIT W/SENSOR,P-20000/30000D
P08679	15365	AIR COMPRESSOR 2HP, 10000,20000
P08680	15428	AIR COMPRESSOR 3HP, P-15000/30000
P08712	15753	FITTING PIPE 3/4"
P08763	15435	PURGE TUBE
P087679	15309	COMPRESSOR 20000D
P08787	15552	SITE TUBE
P08888	15362	DUMP SOLENOID VALVE
P09029	15754	FITTING
P09146	15486	REBUILD KIT, P3271
P09250	15360	OPTICAL SENSOR
P09305	15286	REGULATOR REPAIR KIT

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
P09577	15535	CIRCUIT BREAKER
P09881F101	15726	PURGE ORIFICE
P09881F118	15725	PURGE ORIFICE
P09889	15695	4-WAY VALVE
P11396	15273	DEHYDRATOR SPRING
P11576	15751	AIR-COMPRESSSOR 115/220 1 60HZ
P1291	15581	STREET ELBOW 1/4"
P1336	15755	FITTING
P15168	15078	TOWER INLET FILTER
P15169	15226	FILTER, OUTLET
P15186	15079	FILTER, CONDENSOR
P15286	15081	SWITCH,ON/OFF
P15288	15312	1/4 AMP FUSE
P15289	15082	HEATER (MODEL 16000)
P15337	15301	SWITCH, BY-PASS ALARM
P15372	15083	4-WAY VALVE 8/12D
P15373	15084	AIR COMPRESSOR
P15373R	15085	REBUILT COMPRESSOR (MUST SEND CORE)
P15376	15086	CAPILLARY TUBE 12'1"
P15386	15087	FLEX TUBING
P15390	15430	4-WAY REPLACEMENT KIT
P15451	15088	MAINTENANCE KIT,P-16000-24000
P15451D	15089	MAINTENANCE KIT,P-16000/24000D
P15452	15090	STRAINER,ELEMENT
P15453	15091	FILTER, ELEMENT
P15487	15093	4-WAY VALVE 16/24
P15674	15623	TEST PLUG
P2003061	15206	TIMER, CYCLE, 115V
P2003062	15311	TIMER,CYCLE 220V
P2003851	15335	CYCLE TIMER MOTOR
P2003852	15457	CYCLE TIMER MOTOR
P20040312	15098	CHAMBER 12"
P20040312R	15099	CHAMBER 12" REPACK
P20040320	15733	DESICANT TOWER 20 INCH NEW
P2004036	15296	DESICANT CHAMBER, 6 INCH NEW
P2004036R	15100	CHAMBER 6" REPACK
P2004039	15333	DESICANT TOWER, 9 INCH NEW
P2004039R	15101	CHAMBER 9" REPACK
P20040426	15737	PURGE ORIFICE
P20040434	15738	PURGE ORIFICE
P20040440	15740	PURGE ORIFICE
P20040441	15741	PURGE ORIFICE
P200404XX	15102	PURGE ORIFICE
P200405	15336	MOISTURE INDICATOR
P200498	15103	SOLENOID VALVE REPAIR KIT
P200498S	15515	VALVE REPAIR KIT, HONEYWELL
P200499	15104	HEATLESS DRYER KIT
P200499S	15369	MAINTENANCE KIT, HEATLESS DRYER
P2323	15106	O-RINGS
P241960064	15381	PANEL REGULATOR
P300495P	15355	AIR MANIFOLD
P300499P	15417	MANIFOLD W/ BRACKETS

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
P3005021	15320	DEHYDRATOR SPRING
P3005052	15857	AIR MANIFOLD COVER
P300507	15481	SPRING, BALL CHECK
P3165	15109	SWITCH, PRESSURE AIR COMP
P3197	15110	GAUGE, PRESSURE 0-100PSI
P3220	15384	HUMIDITY BY-PASS VALVE
P3225	15111	HUMIDITY SOLENOID VALVE
P3271	15113	AIR COMPRESSOR,220/1/60
P3272	15115	BY-PASS RELIEF VALVE, P-15000
P3273	15116	MOTOR, FAN, P-15000,P-16000,P-24000
P3276	15117	VALVE CONTROL,WATER FLOW
P3282	15118	VALVE, SOLENOID
P3310	15119	RELAY, 115V
P3311	15120	RELAY, 230V
P3315	15375	FUSE, 4A
P3391	15299	CHECK VALVE
P3422	15290	LOW PRESSURE REGULATOR
P3450	15121	ALARM LAMP
P3468	15122	POWER CONTACTOR 16/24
P34691	15123	OVERLOAD RELAY
P3487	15756	FITTING
P3500	15124	BI-ANNUAL MAINTENANCE KIT
P3757	15544	NEEDLE VALVE 1/4" MPT X 1/4" POLY
P3764	15757	FITTING
P3801	15748	3/8" PLASTIC TUBING
P38063	15734	COMPRESSOR 1/6HP 110V
P3860	15207	MAINTENANCE KIT W/O VALVE PLATE
P3861	15125	SEAL, PISTON
P3862	15126	RING, PISTON
P3864	15127	SLEEVE, MANIFOLD
P3865	15128	MAINTENANCE KIT
P3865LV		MAINT KIT FOR HP GAST W
P3866	15129	HEAD GASKET
P3867	15130	VALVE, OUTLET
P3868	15131	VALVE, INLET
P3869	15132	CYLINDER GASKET
P3870	15133	PLATE, VALVE
P3871	15134	SHROUD
P3872	15135	PISTON ROD ASSY.1/2,3/4HP
P3873	15136	FAN
P3874	15137	CYLINDER
P3875	15138	CYLINDER HEAD
P3877	15308	CHECK VALVE
P3963	15139	FLOAT SWITCH
P39663	15140	AIR COMPRESSOR, 115/1/60-3/4
P39663L	15141	AIR COMP. 110/1/60 3/4HP
P39663LS	15622	AIR COMPRESSOR ASSY 115-1-60,3/4 H
P39664L	15470	AIR COMPRESSOR 3/4HP
P3970	15512	1/4" TUBE O.D. SLEEVE
P3981	15142	RIDER RING, 3/4 HP
P3986	15143	INTAKE FILTER FELT
P3996	15144	VALVE, SAFTEY

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
P3998	15145	PLUG PIPE
P400308	15853	BASE AND YOKE ASSY
P4003081	15151	VALVE, SOLENOID 115V
P40030811	15152	COIL ASSEMBLY
P40030821	15155	COIL ASSEMBLY
P400308DC1	15292	VALVE, SOLENOID 53VDC
P400308DC11	15518	COIL 53VDC
P400308DC12	15519	COIL 106VDC
P400308DC2	15293	VALVE, SOLENOID 106VDC
P400308DC21	15565	SOLENOID COIL
P400311	15736	TIMER SWITCH
P400312904	15156	O-RING
P400312908	15480	O-RING (DEHYDRATOR)
P400312924	15478	O-RING (DEHYDRATOR)
P400313018	15146	O-RING (DEHYDRATER)
P400313110	15479	O-RING (DEHYDRATOR)
P400313209	15149	O-RING (DEHYDRATER)
P4003611	15859	SCREW 6/32 X 3/8" PPMS
P4003612	15852	SCREW 10/24 X 5/8 PAN MACHINE
P400375	15482	BALL CHECK
P4004	15422	CYLINDER 1/3, 1/6HP
P40040312	15302	CHAMBER 12"
P400589DC1	15218	SOLENOID VALVE, 53 VDC
P400589DC11	15735	SOLENOID VALVE COIL
P400589DC2	15219	SOLENOID VALVE, 106 VDC
P400589DC21	15614	COIL, 106VDC (230V DRYER)
P4021111	15159	SILICA GEL 1LB.
P4022	15477	FAN BLADE (1/6, 1/3HP)
P4024	15160	MANIFOLD ELBOW (3/4HP)
P4025	15161	CYLINDER, HEAD SCREW
P4026	15162	LOCK WASHER
P4030	15164	ECCENTRIC D
P4033	15441	SHROUD SCREW
P4040	15165	SQUARE KEY
P4041	15166	RETAINING RING
P4050	15471	CROSSOVER MANIFOLD
P4156	15168	CORD, SENSING ELEMENT
P4157	15337	ADAPTOR
P4161	15169	SITE TUBE ASSY.
P4323	15170	MAINTENANCE KIT, P-550
P4524	15171	GAUGE, PRESSURE 0-15PSI
P4547	15172	RELAY, ALARM SWITCHING
P4562	15173	MOTOR, FAN
P4564	15174	SWITCH,PRESSURE AIR COMPRESSOR
P4582	15175	VIBRATION MOUNT
P4582S	15616	RUBBER MOUNT SOFT
P4634	15176	CAPACITY CONTROL VALVE
P4642	15287	PRE-COOLER ASSEMBLY
P4721	15629	HEATLESS DRYER ASSY, 12"
P4781	15328	BACK PRESSURE REGULATOR
P50001285	15177	HUMIDITY BY-PASS VALVE
P50001286	15215	RELAY

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
P5000612	15358	GAUGE, PRESSURE, HIGH PRESSURE
P5000629	15357	GAUGE, PRESSURE, LOW PRESSURE
P5000633C	15354	HIGH - LOW PRESSURE ALARM
P5000635	15182	GAUGE, TEMPERATURE 16000
P5000647AA	15210	HUMIDISTAT
P5000647C	15494	CABLE, SENSING ELEMENT
P5000647D	15183	SENSING ELEMENT
P5000647J	15574	GLAND NUT
P500066	15184	SAFETY RELIEF VALVE
P5000843	15339	START STOP SWITCH
P5000844	15359	SWITCH, HEATER, REFRIGERATION
P6500WKIT	15683	MAINTENANCE KIT P-6500W
P7355	15542	BUSHING 1/4" MPT X 1/8" FPT BRASS
P7469	15538	COUPLING 1/8" FPT BRASS
P8030A	15553	1 QT. CAN SILICA GEL BLUE
P8088	15234	SCREW
P8206	15690	RED LIGHT
P8207	15692	WHITE LIGHT
P8525	15758	FITTING
P8550	15759	FITTING
P8805	15193	FLOW METER, AIR
P8818	15194	ALARM, PRESSURE
P9644	15223	WIRE HARNESS (SM. BLACK)
P9832	15475	COMPRESSOR RELAY
PAT1774	15684	CABINET FAN SWITCH
PB079	15543	TEE - 1/8" MALE BRANCH BRASS
PB101	15198	GAUGE, 0-100LBS
PB110	15415	FAN MOTOR
PB117	15213	SWITCH, START-STOP
PB118	15203	HEAT THERMOSTAT
PB119	15204	FAN THERMOSTAT
PB431	15352	HOSE DISCHARGE
PDPP25A7	15760	FITTING
PEC419C	15488	3/8" x 1/8" MALE ELBOW
PEC419D	15487	3/8" x 1/4" NPT MALE ELBOW BRASS
PEC426	15314	PLASTIC SHEATH FITTING
PEC705FL	15517	AIR TAP FITTING TYPE E
PEC724A	15315	"C" CHECK VALVE
PEC729	15217	BUFFERING HOSE ASSY.
PHF200112441	15227	DRYING TOWER ASSEMBLY
PHF200112XXX	15424	HEATLESS DRYER
PHF2C112034	15624	DRYER ASSY-HEATLESS, 12", 120 VAC
PHF2C112036	15742	HEATLESS AIR DRYER
PHF2C112040	15743	HEATLESS AIR DRYER
PHF2C112041	15664	HEATLESS DRYER, 12", 120 VAC
PHF2C212034	15744	HEATLESS AIR DRYER
PHF2C212037	15745	HEATLESS AIR DRYER
PHF2C212041	15746	HEATLESS AIR DRYER
PHF2C212XXX	15211	HEATLESS DRYER 12" S.S.
PMP25A1	15768	FITTING
PMP25A19	15500	1/4" TUBE O.D. X 1/8" MPT
PMP25A30	15506	1/4" TUBE X 1/8" MPT ELBOW

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
PMP25A39	15511	1/4" O.D. TUBING - PER FOOT
PMP25A43	15769	FITTING
PMP25A44	15496	3/8" TUBE O.D. X 1/8"MPT
PMP25A45	15770	FITTING
PMP25A49	15771	FITTING
PMP25A57	15752	CONNECTOR
PMP25A77	15772	FITTING
PMP25A84	15773	FITTING
PMP26A16	15774	FITTING
PMP26A19	15501	3/8" TUBE O.D. X 1/8" MPT
PMP26A20	15503	3/8" TUBING O.D. PER FOOT
PMP26A25	15775	FITTING
PP20040436	15739	PURGE ORIFICE
PPEC401	15510	C FLANGE
PPEC402	15776	FITTING
PPEC403	15777	FITTING
PPEC407A	15778	FITTING
PPEC407B	15779	FITTING
PPEC407C	15780	FITTING
PPEC419A	15781	FITTING
PPEC419B	15782	FITTING
PPEC419C	15783	FITTING
PPEC419D	15784	FITTING
PPEC419G	15785	FITTING
PPEC420A	15786	FITTING
PPEC420B	15787	FITTING
PPEC420C	15788	FITTING
PPEC420D	15789	FITTING
PPEC420E	15790	FITTING
PPEC420F	15791	FITTING
PPEC421A	15792	FITTING
PPEC421B	15505	3/8" UNION O.D.
PPEC421C	15793	FITTING
PPEC422B	15794	FITTING
PPEC422D	15795	FITTING
PPEC422E	15796	FITTING
PPEC423A	15509	1/4" O.D. X 1/8"MPT BRANCH TEE
PPEC423B	15797	FITTING
PPEC423C	15798	FITTING
PPEC423D	15799	FITTING
PPEC423E	15800	FITTING
PPEC424B	15508	3/8" O.D. UNION TEE
PPEC424C	15801	FITTING
PPEC425C	15802	FITTING
PPEC426	15803	FITTING
PPEC426A	15545	F FLANGE FITTING
PPEC427C	15804	FITTING
PPEC430C	15805	TUBING - PER FT.
PPEC432A	15507	3/8" 3 TUBE BUNDLE- PER FOOT
PPEC432C	15353	3/8" TUBING 10 BUNDLE PER FOOT
PPEC501	15806	FITTING
PPEC502	15807	FITTING

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
PPEC503	15521	C PRESSURE TESTING VALVE
PPEC504	15808	FITTING
PPEC505	15809	FITTING
PPEC506	15810	FITTING
PPEC507A	15811	FITTING
PPEC507B	15812	FITTING
PPEC508	15813	FITTING
PPEC510	15814	FITTING
PPEC526	15815	FITTING
PPEC527	15529	DIRECTION OF FLOW INDICATOR
PPEC546	15458	PORTABLE FLOWRATOR
PPEC548	15528	MOISTURE SEPERATOR
PPEC560	15485	AUXILIARY HUMIDITY ALARM
PPEC636	15816	FITTING
PPEC638	15817	FITTING
PPEC639	15818	FITTING
PPEC639-1	15819	FITTING
PPEC642	15820	FITTING
PPEC643	15821	FITTING
PPEC702F	15761	FITTING
PPEC703	15495	C PLASTIC PIPE FITTING 1/4"PORT
PPEC703C	15762	FITTING
PPEC704	15822	FITTING
PPEC704G	15763	FITTING
PPEC705	15497	E PLASTIC PIPE FITTING, 1/8" FPT
PPEC705E	15764	FITTING
PPEC706	15765	FITTING
PPEC707	15766	FITTING
PPEC708	15767	FITTING
PPEC714	15823	FITTING
PPEC714A	15824	FITTING
PPEC715	15499	B PLASTIC TUBE CONNECTOR
PPEC716	15825	FITTING
PPEC717	15826	FITTING
PPEC718	15827	FITTING
PPEC719	15828	FITTING
PPEC720	15829	FITTING
PPEC720A	15830	FITTING
PPEC720B	15831	FITTING
PPEC720C	15832	FITTING
PPEC721	15833	FITTING
PPEC724A	15498	C AUTOMATIC SHUT-OFF VALVE
PPEC725	15504	BY-PASS VALVE, W/3/8" TUBE O.D.
PPEC726	15835	FITTING
PPEC726B	15836	FITTING
PPEC726C	15837	FITTING
PPEC727	15862	PIPE PLUG 1/4" MPT
PPEC801	15838	FITTING
PPEC802	15839	FITTING
PPEC809	15840	FITTING
PPEC814	15841	FITTING
PPEC817	15842	FITTING

PUREGAS PARTS

PUREGAS PART #	PSI PART #	DESCRIPTION
PPEC818	15843	FITTING
PPEC840	15844	FITTING
PPEC849	15845	FITTING
PPEC853	15846	FITTING
PS142	15199	QUICK CONNECT
PS161	15539	COUPLING 1/4" FPT BRASS
PS297	15847	FITTING
PS420	15848	FITTING
PS429	15849	FITTING
T16816	15520	2-WAY SOLENOID VALVE
T1787	15850	FITTING